



TREE PRESERVATION PLAN

Tree Number	Size	Common Name	Remove/Retain
1	28" DBH	Willow	Remove
2	8" DBH	Maple	Remove
3	14" DBH	Maple	Remove
4	14" DBH	Maple	Remove
5	24" DBH	Maple	Remove
6	6" DBH	Maple	Remove
7	6" DBH	Maple	Remove
8	6" DBH	Maple	Remove
9	22" DBH	Maple	Remove
10	12" DBH	Maple	Remove
11	12" DBH	Maple	Remove
12	10" DBH	Maple	Remove
13	20" DBH	Maple	Remove
14	6" DBH	Maple	Remove
15	18" DBH	Locust	Remove
16	10" DBH	Maple	Remove
17	24" DBH	Maple	Remove
18	12" DBH	Walnut	Remove
19	12" DBH	Maple	Remove
20	16" DBH	Maple	Remove
21	26" DBH	Maple Multiple	Remove
22	22" DBH	Deciduous	Remove
23	12" DBH	Maple	Remove
24	38" DBH	Maple	Remove



25	14" DBH	Maple	Remove
26	8" DBH	Maple	Remove
27	14" DBH	Maple	Remove
28	14" DBH	Maple	Remove
29	6" DBH	Cherry	Remove
30	6" DBH	Locust	Remove
31	8" DBH	Locust	Remove
32	8" DBH	Locust	Remove
33	26" DBH	Maple	Remove
34	12" DBH	Locust	Remove
35	22" DBH	Locust	Remove
36	6" DBH	Maple	Remove
37	10" DBH	Cherry	Remove
38	8" DBH	Maple	Remove
39	28" DBH	Maple	Remove
40	6" DBH	Maple	Remove
41	14" DBH	Cherry	Remove
42	12" DBH	Cherry	Remove
43	6" DBH	Maple	Remove
44	18" DBH	Locust	Remove
45	14" DBH	Maple	Remove
46	18" DBH	Locust	Remove
47	12" DBH	Cherry	Remove
48	12" DBH	Maple	Remove



49	10" DBH	Maple	Remove
50	12" DBH	Maple	Remove
51	14" DBH	Maple	Remove
52	38" DBH	Cottonwood	Remove
53	16" DBH	Deciduous	Remove
54	6" DBH	Cherry	Remove
55	6" DBH	Cherry	Remove
56	12" DBH	Locust	Remove
57	20" DBH	Locust	Remove
58	24" DBH	Locust	Remove
59	18" DBH	Locust	Remove
60	6" DBH	Cherry	Remove
61	16" DBH	Maple	Remove
62	16" DBH	Maple	Remove
63	24" DBH	Locust	Remove
64	24" DBH	Cherry	Remove
65	22" DBH	Locust	Remove
66	12" DBH	Maple	Remove
67	24" DBH	Locust	Remove
68	24" DBH	Locust	Remove
69	24" DBH	Maple	Remove
70	8" DBH	Maple	Remove
71	18" DBH	Maple	Remove
72	24" DBH	Maple	Remove
73	18" DBH	Pine	Remove

74	12" DBH	Maple	Remove
75	8" DBH	Pine	Remove
76	18" DBH	Pine	Remove
77	16" DBH	Pine	Remove
78	16" DBH	Spruce	Remove
79	8" DBH	Spruce	Remove
80	10" DBH	Spruce	Remove
81	10" DBH	Spruce	Remove
82	12" DBH	Spruce	Remove
83	8" DBH	Spruce	Remove
84	6" DBH	Spruce	Remove
85	16" DBH	Maple	Remove
86	6" DBH	Spruce	Remove
87	6" DBH	Spruce	Remove
88	12" DBH	Japanese Maple	Remove
89	12" DBH	Maple	Remove
90	14" DBH	Maple	Remove
91	6" DBH	Maple	Remove
92	10" DBH	Locust	Remove
93	10" DBH	Locust	Remove
94	16" DBH	Cherry	Remove
95	12" DBH	Maple	Remove
96	12" DBH	Maple	Remove
97	6" DBH	Maple	Remove
98	10" DBH	Locust	Remove
99	6" DBH	Maple	Remove
100	32" DBH	Maple	Remove
101	18" 10" DBH	Maple	Remove
102	14" DBH	Deciduous	Remove
103	10" DBH	Deciduous	Remove
104	10" DBH	Cottonwood	Remove
105	34" 28" DBH	Cottonwood	Remove
106	18" DBH	Maple	Remove
107	20" DBH	Maple	Remove
108	34" DBH	Cottonwood	Remove
109	34" DBH	Cottonwood	Remove
110	34" DBH	Maple	Remove
111	16" DBH	Maple	Remove
112	24" DBH	Maple	Remove
113	14" DBH	Maple Multiple	Remove
114	6" DBH	Maple	Remove
115	12" DBH	Walnut	Remove
116	6" DBH	Deciduous	Remove
117	6" DBH	Deciduous	Remove
118	8" DBH	Deciduous	Remove
119	6" DBH	Deciduous	Remove
120	10" DBH	Deciduous	Remove
121	6" DBH	Hemlock Multiple	Remove
122	38" DBH	Maple	Remove

123	16" DBH	Deciduous	Remove
124	24" 22" DBH	Deciduous	Remove
125	24" DBH	Spruce	Remove
126	38" DBH	Spruce	Remove
127	30" DBH	Maple	Remove
128	24" 16" DBH	Deciduous	Remove
129	6" DBH	Deciduous	Remove
130	6" DBH	Deciduous	Remove
131	8" DBH	Deciduous	Remove
132	8" DBH	Birch Multiple	Remove
133	30" 30" DBH	Maple	Remove
134	6" DBH	Walnut	Remove
135	6" DBH	Cedar Multiple	Remove
136	10" DBH	Deciduous	Remove
137	6" DBH	Locust	Remove
138	6" DBH	Maple	Remove
139	6" DBH	Maple	Remove
140	8" DBH	Deciduous	Remove
141	6" DBH	Locust	Remove
142	6" DBH	Deciduous	Remove
143	6" DBH	Locust	Remove
144	6" DBH	Locust	Remove
145	16" DBH	Deciduous	Remove
146	24" 22" DBH	Deciduous	Remove
147	18" DBH	Locust	Remove
148	30" DBH	Spruce	Remove
149	32" DBH	Spruce	Remove
150	46" DBH	Oak	Remove
151	10" DBH	Cedar	Remove
152	6" DBH	Cedar	Remove
153	12" DBH	Cedar	Remove
154	8" DBH	Cedar	Remove
155	8" DBH	Cedar	Remove
156	12" DBH	Cedar	Remove
157	8" DBH	Cedar Twin	Remove
158	28" DBH	Spruce	Remove
159	24" DBH	Spruce	Remove
160	24" DBH	Spruce	Remove
161	18" DBH	Spruce	Remove
162	26" DBH	Spruce	Remove
163	6" DBH	Birch	Remove
164	24" DBH	Cherry	Remove
165	18" DBH	Maple	Remove
166	26" 20" DBH	Maple	Remove
167	6" DBH	Maple	Remove
168	8" DBH	Maple	Remove
169	36" DBH	Tulip	Remove
170	18" DBH	Maple	Remove

171	6" DBH	Locust	Remove
172	18" DBH	Deciduous	Remove
173	8" DBH	Locust	Remove
174	8" DBH	Locust	Remove
175	6" DBH	Locust	Remove
176	6" DBH	Tulip	Remove
177	12" DBH	Locust	Remove
178	10" DBH	Maple Multiple	Remove
179	14" DBH	Locust	Remove
180	6" DBH	Walnut	Remove
181	8" DBH	Walnut	Remove
182	6" DBH	Cherry	Remove
183	8" DBH	Cherry Twin	Remove
184	8" DBH	Cherry	Remove
185	8" DBH	Locust	Remove
186	6" DBH	Locust	Remove
187	8" DBH	Deciduous Twin	Remove
188	8" DBH	Locust	Remove
189	28" DBH	Walnut	Remove
190	8" DBH	Locust	Remove
191	8" DBH	Deciduous	Remove
192	8" DBH	Locust	Remove
193	8" DBH	Locust	Remove
194	6" DBH	Locust	Remove
195	18" DBH	Cherry	Remove
196	6" DBH	Locust	Remove
197	14" DBH	Locust	Remove
198	10" DBH	Walnut	Remove
199	12" DBH	Deciduous	Remove
200	20" DBH	Locust	Remove
201	10" DBH	Cherry	Remove
202	10" DBH	Deciduous	Remove
203	16" DBH	Cherry	Remove
204	6" DBH	Locust	Remove
205	6" DBH	Locust	Remove
206	6" DBH	Deciduous	Remove
207	6" DBH	Locust	Remove
208	10" DBH	Locust	Remove
209	14" DBH	Locust	Remove
210	8" DBH	Cherry	Remove
211	8" DBH	Maple	Remove
212	8" DBH	Maple	Remove
213	26" DBH	Pine	Remove
214	8" DBH	Cherry	Remove
215	20" DBH	Cherry	Remove
216	6" DBH	Locust	Remove
217	6" DBH	Maple	Remove
218	6" DBH	Locust	Remove
219	6" DBH	Maple	Remove
220	24" DBH	Locust	Remove

246	6" DBH	Locust	Remove	381	12" DBH	Maple	Remain	517	18" DBH	Maple	Remain
247	6" DBH	Cherry	Remove	382	34" DBH	Oak	Remove	518	6" DBH	Maple	Remain
248	22" DBH	Walnut	Remove	383	28" DBH	Maple	Remain	519	8" DBH	Maple	Remain
249	22" DBH	Walnut	Remove	384	24" DBH	Oak	Remain	520	6" DBH	Maple	Remain
249	8" DBH	Locust	Remove	385	10" DBH	Maple	Remain	521	6" DBH	Maple	Remain
250	14" DBH	Deciduous	Remove	386	12" DBH	Maple	Remain	522	6" DBH	Maple	Remain
251	22" DBH	Deciduous	Remove	387	14" DBH	Maple	Remain	523	22" DBH	Locust	Remain
252	6" DBH	Deciduous	Remove	388	10" DBH	Maple	Remain	524	18" DBH	Maple	Remove
253	16" DBH	Walnut	Remove	389	14" DBH	Maple	Remain	525	22" DBH	Locust	Remain
254	10" DBH	Locust	Remove	390	22" DBH	Maple	Remain	526	14" DBH	Maple	Remain
255	24" DBH	Maple Multiple	Remove	391	6" DBH	Maple	Remove	527	8" DBH	Maple	Remove
256	6" DBH	Maple	Remove	392	28" DBH	Pine	Remove	528	6" DBH	Maple	Remove
257	42" DBH	Cottonwood	Remove	393	22" DBH	Oak	Remove	529	18" DBH	Oak	Remove
258	6" DBH	Maple	Remove	394	10" DBH	Hickory	Remove	530	6" DBH	Maple	Remain
259	14" DBH	Tree of Heaven	Remove	395	6" DBH	Maple Twin	Remove	531	12" DBH	Birch	Remove
260	8" DBH	Tree of Heaven	Remove	396	10" DBH	Hickory	Remove	532	12" DBH	Ash	Remove
261	22" DBH	Walnut	Remove	397	30" DBH	Hickory	Remove	533	12" DBH	Maple	Remain
262	20" DBH	Ash	Remove	398	8" DBH	Maple	Remove	534	10" DBH	Maple	Remove
263	8" DBH	Cherry	Remove	399	6" DBH	Maple	Remove	535	8" DBH	Maple	Remove
264	6" DBH	Maple	Remove	400	34" DBH	Maple	Remove	536	10" DBH	Maple	Remove
265	14" DBH	Cherry	Remove	401	6" DBH	Maple	Remove	537	10" DBH	Hemlock	Remove
266	10" DBH	Locust	Remove	402	8" DBH	Maple	Remove	538	12" DBH	Oak	Remove
267	10" DBH	Locust	Remove	403	30" DBH	Oak	Remove	539	24" DBH	Maple	Remain
268	18" DBH	Locust	Remove	404	16" DBH	Birch	Remove	540	34" DBH	Pine	Remove
269	8" DBH	Locust	Remove	405	6" DBH	Maple	Remove	541	28" DBH	Maple	Remove
270	8" DBH	Locust	Remove	406	12" DBH	Birch	Remove	542	24" DBH	Maple	Remove
271	16" DBH	Maple	Remove	407	8" DBH	Maple	Remove	543	28" DBH	Maple	Remove
272	16" DBH	Maple	Remove	408	12" DBH	Maple	Remove	544	36" DBH	Pine	Remove
273	10" DBH	Maple	Remove	409	6" DBH	Maple	Remove	545	16" DBH	Hemlock	Remove
274	22" DBH	Maple	Remove	410	8" DBH	Maple	Remove	546	20" DBH	Hemlock	Remove
275	6" DBH	Maple	Remove	411	12" DBH	Maple	Remove	547	16" DBH	Birch	Remove
276	6" DBH	Maple	Remove	412	6" DBH	Maple	Remove	548	36" DBH	Oak	Remove
277	6" DBH	Cherry	Remove	413	12" DBH	Maple	Remove	549	10" DBH	Cedar	Remove
278	6" DBH	Locust Multiple	Remove	414	22" DBH	Pine	Remove	550	16" DBH	Cedar	Remove
279	6" DBH	Locust	Remove	415	20" DBH	Pine	Remove	551	10" DBH	Cedar	Remove
280	6" DBH	Maple	Remove	416	12" DBH	Pine	Remove	552	12" 8" 6"	Oak	Remove
281	12" DBH	Locust	Remove	417	8" DBH	Maple	Remove	553	40" DBH	Pine	Remove
282	14" DBH	Locust	Remove	418	6" DBH	Maple	Remove	554	10" DBH	Deciduous	Remove
283	12" DBH	Maple Twin	Remove	419	24" DBH	Oak	Remove	555	22" DBH	Deciduous	Remove
284	14" DBH	Cherry	Remove	420	12" DBH	Maple	Remove	556	12" DBH	Deciduous Triple	Remove
285	8" DBH	Cherry	Remove	421	20" DBH	Maple	Remove	557	18" DBH	Pine	Remove
286	8" DBH	Cherry	Remove	422	6" DBH	Maple	Remove	558	10" DBH	Deciduous Triple	Remove
287	10" DBH	Cherry	Remove	423	16" DBH	Maple	Remove	559	8" DBH	Dw. Twain	Remove
288	6" DBH	Maple	Remove	424	12" DBH	Maple	Remove	560	12" DBH	Deciduous Multiple	Remove
289	30" DBH	Maple	Remove	425	10" DBH	Maple	Remove	561	8" DBH	Ash	Remove
290	16" DBH	Maple	Remove	426	48" DBH	Oak	Remove	562	28" DBH	Maple	Remove
291	8" DBH	Maple	Remove	427	12" DBH	Maple	Remove	563	24" DBH	Maple	Remove
292	10" DBH	Maple	Remove	428	14" DBH	Maple	Remove	564	34" DBH	Maple	Remove
293	8" DBH	Maple	Remove	429	12" DBH	Maple	Remain	565	26" DBH	Maple	Remove
294	10" DBH	Maple	Remove	430	10" DBH	Maple	Remain	566	28" DBH	Maple	Remove
295	6" DBH	Maple	Remove	431	6" DBH	Maple	Remain	567	24" DBH	Maple	Remove
296	6" DBH	Locust	Remove	432	10" DBH	Maple	Remain	568	26" DBH	Maple	Remove
297	8" DBH	Deciduous Multiple	Remove	433	24" DBH	Pine	Remove	569	8" DBH	Deciduous	Remove
298	10" DBH	Walnut	Remove	434	12" DBH	Maple Twin	Remove	570	40" DBH	Maple	Remove
299	6" DBH	Walnut	Remove	435	18" DBH	Maple	Remain	571	30" DBH	Pine	Remove
300	16" DBH	Cherry	Remove	436	6" DBH	Maple	Remain	572	28" DBH	Maple	Remove
301	10" DBH	Maple	Remove	437	12" DBH	Maple	Remain	573	6" DBH	Maple	Remain
302	8" DBH	Deciduous Multiple	Remove	438	14" DBH	Maple	Remain	574	12" DBH	Willow	Remain
303	30" DBH	Deciduous	Remove	439	6" DBH	Maple	Remove	575	20" DBH	Maple	Remain
304	30" DBH	Spruce	Remove	440	10" DBH	Maple	Remove	576	30" DBH	Maple	Remain
305	12" DBH	Cedar Twin	Remove	441	24" DBH	Maple	Remain	577	30" DBH	Maple	Remain
306	12" DBH	Cedar	Remove	442	24" DBH	Maple	Remain	578	18" DBH	Maple	Remain
307	14" DBH	Cedar	Remove	443	6" DBH	Maple	Remove	579	38" DBH	Cottonwood	Remove
308	16" DBH	Spruce	Remove	444	6" DBH	Maple	Remove	580	6" DBH	Maple	Remain
309	16" DBH	Cedar	Remove	445	6" DBH	Maple	Remove	581	24" DBH	Locust	Remain
310	8" DBH	Maple	Remove	446	12" DBH	Maple	Remove	582	14" DBH	Maple	Remain
311	14" DBH	Ash	Remove	447	14" DBH	Maple	Remove	583	10" DBH	Maple	Remain
312	12" DBH	Maple	Remove	448	14" DBH	Maple	Remain	584	10" DBH	Deciduous	Remain
313	10" DBH	Maple	Remove	449	12" DBH	Maple	Remain	585	14" DBH	Locust	Remain
314	14" DBH	Maple	Remove	450	10" DBH	Maple	Remain	586	6" DBH	Maple	Remain
315	20" DBH	Maple	Remove	451	6" DBH	Maple	Remain	587	6" DBH	Walnut	Remain
316	38" DBH	Maple	Remove	452	30" DBH	Locust	Remain	588	38" DBH	Locust	Remain
317	38" DBH	Tulip	Remove	453	8" DBH	Maple	Remove	589	6" DBH	Cherry	Remain
318	12" DBH	Maple Twin	Remove	454	10" DBH	Locust	Remove	590	30" DBH	Maple	Remain
319	12" DBH	Deciduous	Remove	455	6" DBH	Birch	Remove	591	6" DBH	Cherry	Remain
320	16" DBH	Maple	Remove	456	6" DBH	Birch Twin	Remove	592	10" DBH	Cherry	Remain
321	26" 20"	Deciduous	Remove	457	36" DBH	Oak	Remain	593	8" DBH	Cherry	Remain
322	6" DBH	Maple	Remove	458	10" DBH	Maple	Remove	594	10" DBH	Cherry	Remain
323	6" DBH	Maple	Remove	459	14" DBH	Maple	Remove	595	12" DBH	Cherry	Remain
324	18" DBH	Maple	Remove	460	12" DBH	Maple	Remove	596	8" DBH	Cherry	Remain
325	16" DBH	Deciduous	Remove	461	18" DBH	Maple	Remove	597	12" DBH	Locust	Remain
326	6" DBH	Maple	Remove	462	14" DBH	Maple	Remove	598	10" DBH	Cherry	Remain
327	34" DBH	Spruce	Remove	463	10" DBH	Birch	Remove				
328	32" DBH	Spruce	Remove	464	10" DBH	Maple	Remove				
329	22" DBH	Spruce	Remove	465	8" DBH	Hickory	Remain				
330	14" DBH	Spruce	Remove	466	10" DBH	Elm	Remain				
331	6" DBH	Cedar	Remove	467	22" DBH	Birch	Remain				
332	12" DBH	Spruce	Remove	468	6" DBH	Maple	Remain				
333	12" DBH	Deciduous Triple	Remove	469	6" DBH	Maple	Remove				
334	38" DBH	Cedar	Remove	470	6" DBH	Maple	Remove				
335	16" DBH	Cedar	Remove	471	12" DBH	Maple	Remove				
336	18" DBH	Deciduous	Remove	472	8" DBH	Maple	Remove				
337	12" DBH	Cedar	Remove	473	18" DBH	Maple	Remove				
338	14" DBH	Cedar	Remove	474	12" DBH	Maple Triple	Remove				
339	12" DBH	Cedar	Remove	475	12" DBH	Maple	Remove				
340	14" DBH	Cedar	Remove	476	14" DBH	Maple	Remain				
341	12" DBH	Cedar	Remove	477	10" DBH	Maple	Remain				
342	14" DBH	Cedar Twin	Remove	478	6" DBH	Maple	Remove				
343	36" DBH	Pine	Remove	479	18" DBH	Maple	Remove				
344	26" DBH	Pine	Remove	480	20" DBH	Birch	Remove				
345	20" DBH	Pine	Remove	481	8" DBH	Maple	Remove				
346	8" DBH	Cedar	Remove	482	16" DBH	Maple	Remain				
347	18" DBH	Hemlock	Remove	483	6" DBH	Maple	Remain				
348	12" DBH	Cedar	Remove	484	8" DBH	Maple	Remain				
349	14" DBH	Cedar	Remove	485	12" DBH	Maple	Remain				
350	12" DBH	Cedar	Remove	486	12" DBH	Chesnut	Remain				
351	14" DBH	Cedar	Remove	487	6" DBH	Cedar	Remove				
352	28" DBH	Maple	Remove	488	6" DBH	Cedar	Remove				
353	14" 8" DBH	Deciduous	Remove	489	14" DBH	Maple	Remove				
354	48" DBH	Maple	Remove	490	12" DBH	Maple	Remove				
355	24" DBH	Locust	Remain	491	24" DBH	Maple	Remove				